

**75
m²****PORTABLE REPELLER****INDOOR****CHASES AWAY PESTS**

Rats, mice, dormice, dormice, crawling insects and spiders from outdoor and indoor (terraces, verandas, surrounding, houses, backyard, chicken coops;;)...

The device repels rats, mice, dormice, lerots, martens and crawling insects. It emits ultrasound which prevents rodents from hearing possible danger and disrupts the sensory organs of crawling insects. Their habitat becomes undesirable and they cannot adapt to the ultrasound because its frequency changes constantly.

Exhausted by this stress, they generally leave the area in search of better conditions after a few days.

- Device for indoor use with an operating indicator light.
- **Protects a maximum area of 75 m².**
- Visible effects after 72 hours for mice and insects; 2 weeks for rats.
- Sound frequencies: 8-20 kHz sinusoidal.
- Power supply: 3.7 V lithium battery, 2500 mA, autonomy 15 days.
- Maximum power consumption: 0,25 W.
- **Dimensions : 112 x 75 x 57 mm**

Ultrasonds are inaudible to humans; they bounce off smooth surfaces and are absorbed by soft materials like carpets and curtains. Ultrasonds do not pass through walls or ceilings.

INSTALLATION AND SETTINGS:

- 1) Turn on the device with the "ON/OFF" slider [4]. Place the device 20 to 50 cm above the ground to repel insects, or 5 to 50 cm above the ground to repel rodents.
- 2) Set the buttons according to the target pest:
- 3) Insects or mice: Left cursor [1]: position at the top = insects; Center slider [2]: position at the top = quiet; Right cursor [3]: position at the bottom = normal power, or at the top = high power if present to drive away pests.
- 4) Rodents: Left cursor [1]: position at the bottom = rodents. To chase away rodents if they are present: Center cursor [2]: position at the bottom = audible; Right cursor [3]: position at the top = high power. For preventive use: Center slider [2]: position at the top = quiet; Right cursor [3]: position at the bottom = normal power.
- 5) The device operates intermittently with 5 seconds on and 10 seconds off; the flashing green indicator light attests to proper operation. The indicator light turns red when the battery is low.



WK0344
Box of 1 device + 1 micro USB
cable
Master carton of 6 pcs